



Nilfisk




128337293

Kornmarksvej 1|DK-2605 Brøndby|Denmark|Tel.: (+45) 4323 8100

Quick Start Guide - Excellent 170

Caution: Read the instructions before using the machine




Excellent 170




A




1




2



3




4




A




5




6



7




8




A






9



10




11




A



12






13




A



14




15



CLICK


16



B




1




MAX
1 MPa/10 bar

MAX
40°


2



3




4




B




5




6



7




8




B



9




10




11


11.1



11.2



11.3




B




12




ROUGH NOZZLE



ROUGH



GENTLE 1



GENTLE 2

GENTLE NOZZLE



|||| GENTLE I



🚗 GENTLE I

🚲 GENTLE II

CLICK

CLICK

13



SHORT NOZZLE



B




14


14.1




14.2




14.3




14.4




15




15.1




15.2




15.3



15.4



15.5






16


MIN







MAX




C




1




2



3




C




4


4.1




4.2



5





MAX 2min



6



6.1

6.2




6.3

6.4



7




D

II >5min




1




2


2.1



2.2



2.3



FR
Cet appareil
se recycle

À DÉPOSER
EN MAGASIN



À DÉPOSER
EN DÉCHÈTERIE



OU


Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

E




1

1.1





1.2



2


2.1



2.2




3




4


4.1



4.2




4.3






5


5.1



5.2




6




7

7.1




7.2




E




8




9



10



11




F




1


1.1



1.2




2




3


3.1



3.2




4




F




5



6



7



7.2

